

Canu

canu -p **canu** -d **out_dir** -fast genomeSize=5m stopOnLowCoverage=0
useGrid=false minThreads=16 maxThreads=16 maxMemory=120 -nanopore-raw **reads.fastq.gz**

output filename prefix
output directory name
faster read overlapping (recommended in release notes for genomes <1 Gbp in size)
true size of the reference genome
prevents premature termination in cases of suboptimal input reads
these four options tailor Canu to the computational environment
input read type (changed to -pacbio-raw for PacBio reads)
input read filename

Flye

flye -o **out_dir** --plasmids --meta --genome-size 5m --threads 16 --nano-raw **reads.fastq.gz**

output directory name
enable recovery of small plasmids
enable uneven coverage mode
true size of the reference genome
CPU threads to use
input read type (changed to --pacbio-raw for PacBio reads)
input read filename

Miniasm

miniasm_and_minipolish.sh **reads.fastq.gz** 16

input read filename
CPU threads to use

NECAT

necat.pl bridge **config.txt**

contains read filename, genome size and thread count

Raven

raven --graphical-fragment-assembly **graph.gfa** --threads 16 **reads.fastq.gz**

output graph filename
CPU threads to use
input read filename

Redbean

wtdbg2.pl -o **dbg** -g 5m -t 16 -x **ont** **reads.fastq.gz**

output filename prefix
true size of the reference genome
CPU threads to use
assembly preset (changed to rs for PacBio reads)
input read filename

Shasta

seqtk seq -A **reads.fastq.gz** > reads.fasta
shasta --input reads.fasta --assemblyDirectory **out_dir** --threads 16

input read filename
the output directory name
CPU threads to use